

# LOUP ELITE

## DRILL MONITOR



### DISPLAY FEATURES

- ◆ Easy to use Touch Screen operation
- ◆ True population for up to 32 Rows.
- ◆ Optical blockage for up to 192 Rows.
- ◆ Over 95% Accurate in Soybeans.
- ◆ Displays up to 6 shaft RPM's.
- ◆ Bargraph display for up to 6 hopper levels.
- ◆ Fan Speed
- ◆ Direct readout for Seeds/Acre, Seeds/Foot, Section Average, % of Target and more.
- ◆ View & change up to 4 display options on one screen.
- ◆ Log Field Maps to SD Card
- ◆ Load ISOXML data into any Mapping Software
- ◆ Learn up to 3 implements including planters.



The New **Loup Elite** Drill Monitor provides accurate Seeds/Acre population for any drill or air seeder. Log field maps to internal SD Memory, control active sections and more through easy-to-use Touchscreen display.



3030 N. 40TH ST. • Lincoln, NE 68504  
Toll Free: **877-489-5687**  
**[loupelectronics.com](http://loupelectronics.com)**

# EASY TOUCHSCREEN OPERATION


Select one of 4 selectable windows and choose which functions to display.



Set your Target Population

Live Population Readout

Turn On/Off Drill Sections



Up to 6 Bin Level Sensors

Average Field Population

Field & Total Acres

Configure up to 3 Implements

Enter Your Farm & Field

Select Your Crop & Hybrid

## BACKWARDS COMPATIBLE WITH ALL LOUP SENSORS



Loupe Population Sensor & Blockage Sensor



3030 N. 40TH ST. • Lincoln, NE 68504  
 Toll Free: **877-489-5687**  
[loupelectronics.com](http://loupelectronics.com)