

- Dispays up to 4 shaft RPM's.
- Display for up to 4 hopper levels.
- Direct readout for Seeds/Acre,
 Seeds/Foot and more.
- Customize 2 separate displays for the information you want to see.
- Display up to 4 functions on one screen.

The New **Elite Mini** Drill Monitor provides accurate Population for drills and air seeders. Accurately monitor average or individual sensor population, acres and more through an easy-to-use Color Touchscreen display.



3030 N. 40TH ST. • Lincoln, NE 68504 Toll Free: 877-489-5687 loupelectronics.com

EASY TOUCHSCREEN OPERATION

CUSTOMIZE 2 SELECTABLE WINDOWS WITH THE FUCTION YOU WANT TO DISPLAY.












In/Out of Motion Indication

Live Population Readout

> Live Speed Readout



Up to 4 Bin Level Sensors

Average Field Population

Acres

SAME DEPENDABLE SENSORS



Loup Population Sensor



Hopper Level Sensor



3030 N. 40TH ST. • Lincoln, NE 68504

Toll Free: 877-489-5687 loupelectronics.com